



ecore™

# Maintenance Guidelines

800.322.1923  
[www.ecoreintl.com](http://www.ecoreintl.com)



# Maintenance Guidelines

## Table of Contents

---

<b>I. Composition Rubber Flooring</b>	
a. Daily / Routine Maintenance	3
b. Restorative & Deep Cleaning	4
<b>II. Soft Flooring (Turf)</b>	
a. Daily / Routine Maintenance & Restorative	5
b. Deep Cleaning	6
<b>III. Soft Flooring (Carpet)</b>	
a. Daily / Routine Maintenance & Deep Clean	7
<b>IV. Hard Flooring (Vinyl Sheet &amp; LVT)</b>	
a. Daily & Restorative Maintenance	8
b. Deep Cleaning (Vinyl Sheet Only)	9
<b>V. Floor Surface Disinfecting Process</b>	10

# Composition Rubber Flooring - Daily / Routine Maintenance

## Directions

---

### Dry

- Dust mop, sweep or vacuum all abrasive debris from your floor

### Wet

- Use a cloth or microfiber mop with E-Cleaner diluted 3 ounces E-Cleaner to one- gallon cool water (let dry)

# Rubber Flooring - Restorative / Deep Cleaning Process

## Directions

---

- Dust mop, sweep or vacuum all abrasive debris from your floor
- For **restorative cleaning**, dilute E-Cleaner to 3 ounces E-Cleaner to one-gallon cool water in a pump sprayer
- For **deep cleaning**, dilute E-Strip Floor Stripper to 1-quart E-Strip to 1-gallon cool water for deep cleaning in a pump sprayer
- Apply cleaning solution (E-Cleaner or E-Strip with the appropriate water dilution) to your floor using your pump sprayer and allow the solution to stand for 5 minutes. Apply cleaning solution in manageable sized areas so that it does not dry
- Use a 1.5 HP (175 RPM) rotary floor machine with a red stripping pad to agitate the solution. For a deep cleaning use a black stripping pad
- Use a wet-vac with squeegee head to pick up the stripper solution
- Rinse with clean water using a mop and allow to dry

## Equipment

---



- 1.5 HP (175 RPM) Rotary Floor Machine with Red or Black Stripping Pad
- Sizes: 13 inch, 17 inch, 20 inch
- Used together to agitate E-Strip Floor Stripper



- Wet-vac with squeegee accessory
- Used to pick up stripper solution

# Soft Flooring - Turf

## Daily / Routine Maintenance & Restorative

### Directions

---

#### Daily

- Turf - Vacuum to remove loose dirt and abrasive debris

#### Restorative Turf

- In a pump sprayer, dilute E-Cleaner to 3 ounces E-Cleaner to one-gallon cool water
- Counter Rotating Brush Machine mop to scrub turf

### Equipment

---



- Counter Rotating Brush Machine

# Soft Flooring - Turf Deep Cleaning

## Directions

---

- Pre-vacuum turf to remove loose dirt and abrasive debris
- In a pump sprayer, dilute Enviro Care to the necessary ratio provided on the product label with warm water
- Apply Enviro Care to the turf using your pump sprayer and allow the solution to dwell for 5 minutes - 10 minutes. Dwell time will help break down embedded soils from the turf. Do not allow to dry
- Do not use steam
- Thoroughly rinse and extract the Enviro Care solution using warm water and a portable extractor or self-contained extractor with a recovery tank
- Failure to properly rinse the Enviro Care can result in rapid resoiling of the turf
- After rinsing and extracting, allow the turf to dry

## Equipment

---



- Portable Extractor with Carpet Wand
- 



- Self-Contained Extractor

# Soft Flooring - Carpet

## Daily / Routine Maintenance & Deep Clean

### Directions

---

#### Daily

- Carpet - Vacuum using vacuum with cylinder brush bar

#### Deep Cleaning

- Utilize a hot water extraction method, also known as steam cleaning. With this method, hot water\* or hot water containing a detergent solution is forced into the pile by high pressure. The water, along with the soil, is then immediately extracted.
- Adequate time is needed for drying. During this time, the floor should not be walked on, as the moisture will remove any soil from soles of shoes.

*\*The maximum water temperature should not exceed 150° Fahrenheit*

### Equipment

---



- Portable Extractor with Carpet Wand

# Hard Flooring - Vinyl & LVT

## Daily & Restorative Maintenance

### Directions

---

#### Daily Dry

- Dust mop, sweep or vacuum all abrasive debris from your floor

#### Daily Wet

- Use a cloth or microfiber mop with E-Cleaner diluted 3 ounces E-Cleaner to one- gallon cool water (let dry)

#### Restorative

- Clean using walk behind Auto Scrubber with E-Cleaner diluted 3 ounces E-Cleaner to one- gallon cool water. Allow to dry

### Equipment

---



- Walk behind Auto Scrubber



# Hard Flooring - Deep Cleaning (Vinyl Sheet Only)

## Directions

---

- Dust mop, sweep or vacuum all abrasive debris from your floor
- In a pump sprayer, dilute E-Strip diluted 1-quart E-Strip to one- gallon cool water
- Apply E-Strip to your floor using your pump sprayer and allow the solution to stand for 5 minutes. Apply E-Strip in manageable sized areas so that it does not dry
- Use a 1.5 HP (175 RPM) rotary floor machine with a red stripping pad to agitate the solution
- Use a wet-vac with squeegee head or auto scrubber to pick up the stripper solution
- Rinse with clean water using a microfiber mop and allow to dry

## Equipment

---



- 1.5 HP (175 RPM) Rotary Floor Machine with Red Stripping Pad
- Sizes: 13 inch, 17 inch, 20 inch
- Used together to agitate E-Strip Floor Stripper

# Disinfecting Process

## Directions

---

- Before beginning the disinfecting process, be sure to use all required personal protective equipment (PPE) per the product label

### Option I – Premium Fogger

- Heavily soiled surfaces require cleaning before use. We recommend following the maintenance and cleaning protocols prior to disinfecting.
- For maximum coverage and overall efficiency, use an ultra-low volume (ULV) cold fogger to spray disinfectant onto the surface

### Option II – Pump Sprayer / Handheld Cordless

- Disinfectant can also be applied using an electrostatic sprayer or pump sprayer
- **IMPORTANT:** Thoroughly apply enough disinfectant to remain wet for stated amount of time per product guidelines to properly disinfect
- Allow to dry. If desired, wipe dry

## Equipment

---



- ULV (Ultra Low Volume) Fogger



- Cordless Electrostatic Handheld Sprayer